

MODERN PENCIL

Modern Pencil Plan ©2015 DIY-Modern.com All Rights Reserved. Resale prohibited.



NOTE:

Dimensions can be approximate. Cut 3/4" boards to the desired slice thickness to equal approx. 1/2" total (wood sandwich). Glue the slices together with wood glue. When dry cut the "sandwiches" to 1/8" slices. Groove the slices down the center on both sides to accept the lead, then CA glue the 1/8" thick slices together and sand the edges and point.